Configuration details

- **Using Comport**
  Budrate – 9600

- **Using Ethernet**
  Default ip 192.168.0.7 port number – 4001

IR AVC Class:-

Bike/Autorickshaw/ CarJeep = 1

Tractor /LCV = 2

Truck/Bus = 3

mav3Axle = 5

mav4Axle To 6 Axle = 6

mav7Axle and more = 7

Message :-

STX,01,11111111,11111111,ETX

STX 01 is live Message, its popup every 5 second. If no loop activated.

STX,02,01,00,F,00000,000000003,ETX

STX 02 is class Message, its popup every transaction.

STX – Start of string

02 – type of Message

01 – Vehicle Class

00 – Axle Count

F – Vehicle direction (F- Forward and R – Reverse)

0000 – Wheel_Base

000000003 – transaction Count

ETX – end of string

Network Toll Solution